Existing Conditions

Terminology

Existing Conditions

Phrase commonly used to denote the current environmental conditions within geographic areas considered in an EIS or EIR

Affected Environment

NEPA term for *Existing Conditions*

Environmental Setting

CEQA term for Existing Conditions

Baseline

Any scenario that is used as a basis of comparison in an EIS or EIR.

Affected Environment and Environmental Setting are "baselines" for comparing impacts of alternatives

Existing Conditions

What does it mean?

Existing Conditions = Affected Environment = Environmental Setting

A succinct description of the environmental conditions that will be or could be affected by the alternatives considered in an EIS or EIR. Descriptions are to be no longer than necessary to describe the effects of the alternatives.

Existing Conditions

How is it used?

- Discussion of existing conditions is required in NEPA and CEQA documents under Affected Environment and Environmental Setting
- Describes the current environmental conditions that could be altered in some way by the alternatives considered. Includes historical account of how conditions came about
- Provides a *Baseline* for the analysis and comparison of the alternatives